

## Instructions for McGaughy's 2011+ GM HD 2" FRONT LEVELING KIT



Use the four provided spacers and install on on each shock stud as shown in the picture. Use the new provided flange nuts to install the upper shock into the factory location and tighten to 50 ft lbs. Re-install the lower (bottom) end of the factory front shock into the factory position in the shock mount, using all the original hardware and tighten.