

#33089 DROP SHACKLE INSTRUCTION GUIDE
2002-2010 GM 2500/3500 TRUCKS



1. With the vehicle turned off and in park, use wheel chocks to secure the front of the vehicle.
2. Jack up the rear of the vehicle and place jack stands under the frame on both sides.
3. Place the floor jack under the rear axle and use to relieve pressure on the factory shackles by jacking up the rear end.
4. Unbolt the factory shackles.
5. Install the new drop shackles, bolting them on the same way the factory shackles came off. Use the factory hardware.
6. The top hole will be used for a 2" drop. The bottom hole will be used for a 1" drop.
7. You may need to trim the bed rail if it comes in contact with the new shackle. Relieve the small area of bed rail as needed.
8. Torque all hardware to factory specs. Be sure to retighten all hardware after 1000 miles.