

PART # 34037 2" DROP SPINDLES for 2007-13 GM 1500

2007T Spindles - Must use 17" or larger wheels



- If you are the installer only, and not the owner of the vehicle, please make sure the owner of the vehicle gets these instructions. They contain very important information about the kit, maintainace, and warranty.
- -Before moving forward with installation, please layout all parts from boxes and ensure everything is present. If any parts are missing, please contact McGaughy's Suspension immediately at 559-226-8196.
- -If you alter the finish of any of the provided components, like zinc plating, chroming, or powder-coating, which can cause damage to the strength and structure of the metal, any warranties will be null and void.
- -If any components are ground on or modified in any way, then no returns or exchages will be accepted and any warranties will be null and void.
- -Spindles are shipped with protective coating on surface. This allows them to be delivered to you without rust. We recommend you clean and paint the parts before you install, to protect against any future rust. Remember, spndles are bare metal, and will rust without paint.



559-226-8196 4603 E. VINE AVE. FRESNO, CA 93725 www.mcgaughys.com

WARRANTY INFORMATION

- -McGaughy's warrants all **McGaughy's** products against manufacturer's defects in materials or workmanship for a period of **ONE-YEAR** from the date of original purchase. All McGaughy's spindles carry a **LIFETIME** warranty against manufacturer's defects.
- -Warranty will not extend to any product or part there in, that has been improperly installed, abused, or neglected
- -McGaughy's will not warranty any product(s) that were modified in any way. Check fit all products prior to custom painting, powder-coating, or any form of fabrication (sanding, drilling, painting, chroming, etc).
- -There are **NO WARRANTIES** neither espressed nor implied for powder-coating on any McGaughy's products.
- -McGaughy's is not responsible for damages and/or warranty of other vehicle parts (factory or aftermarket) related or non-related to the install of McGaughy's component(s).
- -Warranty is limited to the repair or replacement (of McGaughy's product only), at McGaughy's discretion. And only after inspection of the defective part, once returned to McGaughy's with proof of purchase, date of purchase, and all shipping costs prepaid.
- -Any cost of labor, freight, incidental or consequential damages are expressly excluded from warranty.

- 1. Remove tie rod nut.
- 2. Remove ABS wire.
- 3. Remove all brake lines and wires from spindle. **DO NOT DISCONNECT BRAKE HOSE FROM CALIPER.**
- 4. Remove caliper bolts. Secure caliper with bungee or wire. Be sure to not stretch any wires or hoses.
- 5. Remove rotor and remove hub assembly.
- 6. On 4wd only, be sure to remove the cv axle.
- 7. Compress coil spring using proper spring compressor and remove.
- 8. Remove upper ball joint nut.
- 9. Remove lower ball joint nut.
- 10. Remove factory spindle from vehicle.
- 11. Install the provided M12 stud into the new drop spindle using the top hole. Be sure to use loctite and torque to 75 lbs.
- 12. Install the hub assembly onto the drop spindle using the provide top M12 bolt and two factory bolts for the lowers. Be sure to loctite the factory bolts too.
- 13. Re-install the coils into the factory location and install the new drop spindles onto the upper and lower ball joints using the provided new hardware. Torque to factory specs.
- 14. **On 4wd only,** you will need to cut off the excess thread on the top ball joint. Be sure to cut flush with the nut.
- 15. Re-install the outer tie rod end into the drop spindle. Torque to factory specs.
- 16. Please note, you may need to cut the excess threads on the lower ball joint. This depends on the wheels you are running. Be sure to check before installing your wheels.
- 17. On 4wd only, re-install the cv axle.
- 18. Re-install rotors and clipers. Be sure to use loctite on the hardware. Torque to factory specs.
- 19. Slide rubber brake hose through the factory mounting brackets so that when they are bolted to the drop spindle, there is no stretching or binding. Then bolt the bracket to the drop spindle using loctite. Be sure to turm the spindle fully to make sure nothing is rubbing, stretched, or pinched.
- 20. Now re-install the wheel and torque to factory specs. Repeat this process on the opposite side.

VEHICLE MUST BE ALIGNED BEFORE DRIVING. RETORQUE LUG NUTS AFTER 10 MILES.