

STOP --READ THIS FIRST

McGAUGHY'S 2000+ TAHOE/SUBURBAN/YUKON/XL KEY WAY INSTRUCTIONS

1. Jack up the front of the vehicle and place jackstands underneath the front of the frame supporting the front but allowing the front suspension to hang freely.
2. Using proper torsion key removing tool, compress torsion key to relieve pressure off of torsion adjustment bolt. (if you do not have this tool you can rent one from your local auto parts store or tool rental supply store.)
3. Using an 18mm socket remove key way bolt.
4. Remove threaded block under the key way.
5. Slide torsion bar toward front of vehicle and key way will fall out.
6. Install new McGaughy's key way making sure counter sunk holes are on the bottom of the key way.
7. Slide torsion bar back towards the rear of the vehicle.
8. Re-install threaded key way block and screw bolt back into key way.
9. Run the bolt down about half the distance of the threads. The amount that is screwed in may need to be adjusted for desired height. (One turn of this adjusting bolt raises or lowers vehicle approximately 1/8")
10. Remove jackstands and release jack.

