



559-226-8196

www.mcgoughys.com

## Part #54364

Air Spacer Kit For 8" Lift Kit

2013-2020 Dodge Ram 3500

w/ Factory Automatic Level Rear Air Suspension

**This air spring spacer kit should be installed by a certified Dodge mechanic. So they may use the original manufacturer's installation instructions for installing the Automatic Level Rear Air Suspension.**



**Kit includes:  
(2) Rear Air Bag Spacers  
All Hardware**

**This bracket is designed to go between the factory air bag and the factory mount on the axle for the automatic level rear air suspension. The spacer comes with four 3/8" x 1-1/4" bolts with locking nuts to bolt the new spacer to the original air bag mount on the axle. Factory air spring hardware will be used to attach the original air spring to the new air bag spacer. Refer to the manufacturer's installation instructions for installing the factory air bag to the newly installed air bag spacer. Make sure all your lines are clear of any moving parts that could cause any rubbing or failure. Make sure nothing is rubbing against any of the air lines or the factory air bags.**